


# NERVE INSTRUCTIONS

#### COPYRIGHT © 2014 WILEY X, INC. ALL RIGHTS RESERVED.

WILEY X, WX, BLACK OPS, logos, tag lines and product names are trademarks or registered trademarks (marcas registradas) of Wiley X, Inc. in the U.S. and other countries. Logos @ 2007-2014 Wiley X, Inc. All rights reserved.









Snap together as shown making sure all hooks are seeded.

#### ADAPTER INSTALLATION




Lift the frame to allow easy access to insert the adapter into the frame.

### **GOGGLE STRAP / GOGGLE FRAME**



The goggle strap is secured to the goggle by inserting the goggle strap pin at (1) into the goggle face frame at (2).

## REMOVE / ATTACH GOGGLE STRAP



Remove or attach goggle strap by positioning the strap perpendicular to the frame as pictured above.

MAINTENANCE: Wiley X lenses are specially coated to offer superior abrasion resistance. Please follow below instructions to prolong the life of your lenses and keep them performing at their best:

Clean lenses with water only.

Do not use solvents or special cleaners.

Use micro-fiber cleaning cloth provided to gently wipe clean.

Never use paper products to clean and avoid wiping lens surface when dry and/or dirty as this may potentially scratch the lens.

WARNING: Wiley X brand eyewear is tested tough. However, impact resistant eyewear is not unbreakable and does not provide unlimited eye protection under all circumstances and conditions. Misused, abused, scratched and/or damaged eyewear can reduce impact protection (and void your limited warranty). Dirty and/or wet eyewear can impair vision and reduce safety (resulting in personal injury and/or property damage). Keep your Wiley X eyewear clean with water only. Do not use solvents or abrasives as it could scratch or damage the product reducing its effectiveness. Store your Wiley X eyewear in the protective case provided to prolong the life of the lenses. Most of all, take all appropriate precautions when wearing your Wiley X eyewear during hazardous and/or dangerous activities and conditions. Wiley X, Inc. is not responsible for personal injury, property damage or losses incurred while using Wiley X brand products.

